




**503**

8 BUTTONS


7 BUTTONS

6 BUTTONS



5 BUTTONS

4 BUTTONS




3 BUTTONS


2 BUTTONS

**503 SLIM**

**SLIM mini**



**502**



**503 USBC**

**H71**

**H71 Mix**

**H71 MIX 2 USB-C**



**H142**







COVER PRESE

SOCKET COVER


502




502-ROUND




503




504




H71




H71 - 1 R



H71 - 2 R




H142




USB-C Caricatori *USB-C Chargers*

H/USB-C | 2 502



H/USB-C | 2 503



H/USB-C | 4 H71

